

L80-R GPS

Protocol Specification

GPS Module Series

Rev. L80-R_GPS_Protocol_Specification_V1.1

Date: 2015-12-03



Our aim is to provide customers with timely and comprehensive service. For any assistance, please contact our company headquarters:

Quectel Wireless Solutions Co., Ltd.

Office 501, Building 13, No.99, Tianzhou Road, Shanghai, China, 200233

Tel: +86 21 5108 6236

Mail: info@quectel.com

Or our local office, for more information, please visit:

<http://www.quectel.com/support/salesupport.aspx>

For technical support, to report documentation errors, please visit:

<http://www.quectel.com/support/techsupport.aspx>

Or Email: Support@quectel.com

GENERAL NOTES

QUECTEL OFFERS THIS INFORMATION AS A SERVICE TO ITS CUSTOMERS. THE INFORMATION PROVIDED IS BASED UPON CUSTOMERS' REQUIREMENTS. QUECTEL MAKES EVERY EFFORT TO ENSURE THE QUALITY OF THE INFORMATION IT MAKES AVAILABLE. QUECTEL DOES NOT MAKE ANY WARRANTY AS TO THE INFORMATION CONTAINED HEREIN, AND DOES NOT ACCEPT ANY LIABILITY FOR ANY INJURY, LOSS OR DAMAGE OF ANY KIND INCURRED BY USE OF OR RELIANCE UPON THE INFORMATION. THE INFORMATION SUPPLIED HEREIN IS SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.

COPYRIGHT

THIS INFORMATION CONTAINED HERE IS PROPRIETARY TECHNICAL INFORMATION OF QUECTEL CO., LTD. TRANSMITTABLE, REPRODUCTION, DISSEMINATION AND EDITING OF THIS DOCUMENT AS WELL AS UTILIZATION OF THIS CONTENTS ARE FORBIDDEN WITHOUT PERMISSION. OFFENDERS WILL BE HELD LIABLE FOR PAYMENT OF DAMAGES. ALL RIGHTS ARE RESERVED IN THE EVENT OF A PATENT GRANT OR REGISTRATION OF A UTILITY MODEL OR DESIGN.

Copyright © Quectel Wireless Solutions Co., Ltd. 2015. All rights reserved.

About the Document

History

Revision	Date	Author	Description
1.0	2015-08-10	Connie ZHOU	Initial
1.1	2015-12-03	Connie ZHOU	1. Added Packet Type 255, 285 and 886 2. Deleted Packet Type 300

Quectel
Confidential

Contents

About the Document.....	2
Contents.....	3
Table Index.....	5
1 Introduction	6
2 Standard NMEA Packet Protocol	7
2.1. GPRMC.....	7
2.2. GPVTG	8
2.3. GPGGA.....	9
2.4. GPGSA	10
2.5. GPGSV	11
2.6. GPGLL.....	13
3 MTK NMEA Packet Protocol	14
3.1. Packet Type: 010 PMTK_SYS_MSG	14
3.2. Packet Type: 011 PMTK_TXT_MSG.....	15
3.3. Packet Type: 001 PMTK_ACK	16
3.4. Packet Type: 101 PMTK_CMD_HOT_START	16
3.5. Packet Type: 102 PMTK_CMD_WARM_START	17
3.6. Packet Type: 103 PMTK_CMD_COLD_START.....	18
3.7. Packet Type: 104 PMTK_CMD_FULL_COLD_START.....	18
3.8. Packet Type: 161 PMTK_CMD_STANDBY_MODE.....	19
3.9. Packet Type: 220 PMTK_SET_POS_FIX	19
3.10. Packet Type: 251 PMTK_SET_NMEA_BAUDRATE.....	20
3.11. Packet Type: 255 PMTK_SET_SYNC_PPS_NMEA.....	21
3.12. Packet Type: 285 PMTK_SET_PPS_CONFIG	21
3.13. Packet Type: 286 PMTK_SET_AIC_ENABLED.....	22
3.14. Packet Type: 301 PMTK_API_SET_DGPS_MODE	23
3.15. Packet Type: 314 PMTK_API_SET_NMEA_OUTPUT	23
3.16. Packet Type: 386 PMTK_API_SET_STATIC_NAV_THD.....	25
3.17. Packet Type: 400 PMTK_API_Q_FIX_CTL	26
3.18. Packet Type: 401 PMTK_API_Q_DGPS_MODE.....	27
3.19. Packet Type: 414 PMTK_API_Q_NMEA_OUTPUT	27
3.20. Packet Type: 605 PMTK_Q_RELEASE	28
3.21. Packet Type: 500 PMTK_DT_FIX_CTL	29
3.22. Packet Type: 501 PMTK_DT_DGPS_MODE.....	29
3.23. Packet Type: 514 PMTK_DT_NMEA_OUTPUT	30
3.24. Packet Type: 705 PMTK_DT_RELEASE	31
3.25. Packet Type: 869 PMTK_EASY_ENABLE.....	32
3.26. Packet Type: 886 PMTK_FR_MODE	33
4 Appendix A Reference.....	34

5 Default Configurations 36

Quectel
Confidential

Table Index

TABLE 1: STRUCTURE OF NMEA MESSAGE	7
TABLE 2: STRUCTURE OF MTK NMEA PACKET	14
TABLE 3: RELATED DOCUMENTS	34
TABLE 4: TERMS AND ABBREVIATIONS	34
TABLE 5: DEFAULT CONFIGURATIONS	36

Quectel
Confidential

1 Introduction

L80-R is a full featured GPS module with super sensitivity. It is characteristic of low power consumption and compact size. The module supports autonomous GPS C/A. It can be used in the positioning, navigation and other industries.

This document describes the software aspects of L80-R. L80-R supports NMEA 0183 standard commands. MTK NMEA extended packet is supported to control and configure L80-R GPS module.

Quectel
Confidential

2 Standard NMEA Packet Protocol

L80-R supports NMEA 0183 standard messages. The following table shows the structure of a NMEA 0183 standard message.

Table 1: Structure of NMEA Message

Filed	Length (Bytes)	Description
\$	1	Each NMEA message starts with '\$'
Talker ID	1~2	'GP' for a GPS receiver
NMEA Message ID	3	NMEA message ID
Data Field	Variable, depend on the NMEA message type	Data fields, delimited by comma ','
*	1	End character of data field
Checksum	2	A hexadecimal number calculated by exclusive OR of all characters between '\$' and '*'
<CR><LF>	2	Each NMEA message ends with 'CR' and 'LF'

NOTE

The default output message of L80-R has the following six sentences: RMC, VTG, GGA, GSA, GSV and GLL.

2.1. GPRMC

RMC, recommended minimum position data (including position, velocity and time).

Example:

```
$GPRMC,060949.000,A,3150.7815,N,11711.9239,E,2.87,314.13,050314,,D*69<CR><LF>
```

Field	Description
-------	-------------

\$	Each NMEA message starts with '\$'
GPRMC	Message ID
UTC Time	Time in format 'hhmmss.sss'
Data Valid	'V'=Invalid 'A'=Valid
Latitude	Latitude in format 'ddmm.mmmm' (degree and minutes)
N/S	'N'=North 'S'=South
Longitude	Longitude in format 'dddmm.mmmm' (degree and minutes)
E/W	'E'=East 'W'=West
Speed	Speed over ground in knots
COG	Course over ground in degree
Date	Date in format 'ddmmyy'
Magnetic Variation	Magnetic variation in degree, not being output
E/W	Magnetic variation E/W indicator, not being output
Positioning Mode	'N'=No fix 'A'=Autonomous GPS fix 'D'=Differential GPS fix
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

2.2. GPVTG

VTG, track made good and ground speed.

Example:
\$GPVTG,0.0,T,,M,0.0,N,0.1,K,A*0C<CR><LF>

Field	Description
\$	Each NMEA message starts with '\$'

GPVTG	Message ID
COG(T)	Course over ground (true) in degree
T	Fixed field, true
COG(M)	Course over ground (magnetic), not being output
M	Fixed field, magnetic
Speed	Speed over ground in knots
N	Fixed field, knots
Speed	Speed over ground in km/h
K	Fixed field, km/h
Positioning Mode	'N'=No fix 'A'=Autonomous GPS fix 'D'=Differential GPS fix
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

2.3. GPGGA

GGA, global positioning system fix data, is the essential fix data which provides 3D location and accuracy data.

Example:

```
$GPGGA,060950.000,3150.7820,N,11711.9231,E,2,8,1.17,23.5,M,0.0,M,0000,0000*5A<CR><LF>
```

Field	Description
\$	Each NMEA message starts with '\$'
GPGGA	Message ID
UTC Time	Time in format 'hhmmss.sss'
Latitude	Latitude in format 'ddmm.mmmm' (degree and minutes)
N/S	'N'=North 'S'=South

Longitude	Longitude in format 'dddmm.mmmm' (degree and minutes)
E/W	'E'=East 'W'=West
Fix Status	'0'=Invalid '1'=GPS fix '2'=DGPS fix
Number of SV	Number of satellites being used (0~12)
HDOP	Horizontal Dilution Of Precision
Altitude	Altitude in meters according to WGS84 ellipsoid
M	Fixed field, meter
GeoID Separation	Height of GeoID (mean sea level) above WGS84 ellipsoid, meter
M	Fixed field, meter
DGPS Age	Age of DGPS data in seconds, empty if DGPS is not used
DGPS Station ID	DGPS station ID, empty if DGPS is not used
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

2.4. GPGSA

GSA, GPS DOP and Active Satellites, provides details on the fix, including the numbers of the satellites being used and the DOP. At most the first 12 satellite IDs are output.

Example:

```
$GPGSA,A,3,18,25,12,193,24,15,22,14,,,,,1.47,1.17,0.89*37<CR><LF>
```

Field	Description
\$	Each NMEA message starts with '\$'
GPGSA	Message ID
Mode	Auto selection of 2D or 3D fix 'M'=Manual, forced to switch 2D/3D mode 'A'=Allowed to automatically switch 2D/3D mode

Fix Status	'1'=No fix '2'=2D fix '3'=3D fix
Satellite Used 1	Satellite used on channel 1
Satellite Used 2	Satellite used on channel 2
Satellite Used 3	Satellite used on channel 3
Satellite Used 4	Satellite used on channel 4
Satellite Used 5	Satellite used on channel 5
Satellite Used 6	Satellite used on channel 6
Satellite Used 7	Satellite used on channel 7
Satellite Used 8	Satellite used on channel 8
Satellite Used 9	Satellite used on channel 9
Satellite Used 10	Satellite used on channel 10
Satellite Used 11	Satellite used on channel 11
Satellite Used 12	Satellite used on channel 12
PDOP	Position Dilution Of Precision
HDOP	Horizontal Dilution Of Precision
VDOP	Vertical Dilution Of Precision
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

2.5. GPGSV

GSV, GPS Satellites in View. One GSV sentence can only provide data for at most 4 satellites, so several sentences might be required for the full information. Since GSV includes satellites that are not used as part of the solution, GSV sentence contains more satellites than GGA does.

Example:

```
$GPGSV,3,1,12,01,05,060,18,02,17,259,43,04,56,287,28,09,08,277,28*77<CR><LF>
```

```
$GPGSV,3,2,12,10,34,195,46,13,08,125,45,17,67,014,,20,32,048,24*74<CR><LF>
```

```
$GPGSV,3,3,12,23,13,094,48,24,04,292,24,28,49,178,46,32,06,037,22*7D<CR><LF>
```

Field	Description
\$	Each NMEA message starts with '\$'
GPGSV	Message ID
Number of Message	Number of messages, total number of GPGSV messages being output (1~3)
Sequence Number	Sequence number of this entry (1~3)
Satellites in View	Total satellites in view
Satellite ID 1	Satellite ID
Elevation 1	Elevation in degree (0~90)
Azimuth 1	Azimuth in degree (0~359)
SNR 1	Signal to Noise Ration in dBHz (0~99), empty if not tracking
Satellite ID 2	Satellite ID
Elevation 2	Elevation in degree (0~90)
Azimuth 2	Azimuth in degree (0~359)
SNR 2	Signal to Noise Ration in dBHz (0 ~ 99), empty if not tracking
Satellite ID 3	Satellite ID
Elevation 3	Elevation in degree (0~90)
Azimuth 3	Azimuth in degree (0~359)
SNR 3	Signal to Noise Ration in dBHz (0~99), empty if not tracking
Satellite ID 4	Satellite ID
Elevation 4	Elevation in degree (0~90)
Azimuth 4	Azimuth in degree (0~359)
SNR 4	Signal to Noise Ration in dBHz (0~99), empty if not tracking
*	End character of data field
Checksum	Hexadecimal checksum

<CR><LF> Each of message

2.6. GPGLL

GLL, Geographic Latitude and Longitude, contains position information, time of position fix and status.

Example:
\$GPGLL,3110.2908,N,12123.2348,E,041139.000,A,A*59<CR><LF>

Field	Description
\$	Each NMEA message starts with '\$'
GPGLL	Message ID
Latitude	Latitude in format 'ddmm.mmmm' (degree and minutes)
N/S	'N'=North 'S'=South
Longitude	Longitude in format 'dddmm.mmmm' (degree and minutes)
E/W	'E'=East 'W'=West
UTC Time	Time in format 'hhmmss.sss'
Data Valid	'V'=Invalid 'A'=Valid
Positioning Mode	'N'=No fix 'A'=Autonomous GPS fix 'D'=Differential GPS fix
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3 MTK NMEA Packet Protocol

This chapter introduces the MTK NMEA packet protocol, which is a set of extension messages of the standard NMEA packet protocol. These messages are used to control and configure L80-R GPS module. The following table shows the structure of a MTK NMEA packet.

Table 2: Structure of MTK NMEA Packet

Filed		Length (Bytes)	Description
	\$	1	Each NMEA message starts with '\$'
	Talker ID	1	'P' for proprietary message
NMEA	Data type	3	Always 'MTK' to indicate MTK proprietary message
Data Filed	Packet type	3	Packet type, from '000' to '999'
	Packet data	Variable, depend on the packet type	Data fields, delimited by comma ','
	*	1	End character of data field
	Checksum	2	A hexadecimal number calculated by exclusive OR of all characters between '\$' and '*'
	<CR><LF>	2	Each NMEA message ends with 'CR' and 'LF'

3.1. Packet Type: 010 PMTK_SYS_MSG

This message is used to automatically output system messages by GPS module.

Data Field:

None

Example:

\$PMTK010,001*2E<CR><LF>

Field	Description
-------	-------------

\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	010
Message	System message '0'=Unknown '1'=Startup '2'=Notification for the host aiding EPO '3'=Notification for the transition to normal mode is successfully done
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.2. Packet Type: 011 PMTK_TXT_MSG

This message is used to automatically output system messages by GPS module.

Data Field:
None
Example:
\$PMTK011,MTKGPS*08<CR><LF>

Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	011
Message	MTKGPS
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.3. Packet Type: 001 PMTK_ACK

Acknowledgement of PMTK command. In order to inform the sender whether the receiver has received the packet, an acknowledge packet PMTK_ACK should return after the receiver receives a packet.

Some commands will cause the GPS module to restart or change the baud rate. There is no PMTK_ACK for those commands as listed below.

- PMTK_CMD_HOT_START
- PMTK_CMD_WARM_START
- PMTK_CMD_COLD_START
- PMTK_CMD_FULL_COLD_START
- PMTK_SET_NMEA_BAUDRATE

Data Field:

\$PMTK001,Cmd,Flag

Example:

\$PMTK001,869,3*37<CR><LF>

Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	001
Command	The packet type that the acknowledge responds
Flag	'0'=Invalid packet '1'=Unsupported packet type '2'=Valid packet, but action failed '3'=Valid packet, action succeeded
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.4. Packet Type: 101 PMTK_CMD_HOT_START

This message is used to hot start the GPS module (use all available data in the NV store). Normally hot start means the GPS module was powered down less than 3 hours (RTC must be alive) and its ephemeris

is still valid. As there is no need for downloading ephemeris, it's the fastest startup method.

Data Field: None Example: \$PMTK101*32<CR><LF>	
Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	101
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.5. Packet Type: 102 PMTK_CMD_WARM_START

This message is used to warm start the GPS module. Warm start means the GPS module has approximate information of time, position and coarse data on satellite positions. But it needs to download ephemeris until it can get a fix. Using this message will force the GPS warm restarted without using the ephemeris data in NV.

Data Field: None Example: \$PMTK102*31<CR><LF>	
Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	102
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.6. Packet Type: 103 PMTK_CMD_COLD_START

This message is used to cold start the GPS module. Using this message will force the GPS cold restarted without using any prior location information, including time, position, almanacs and ephemeris data.

Data Field: None Example: \$PMTK103*30<CR><LF>	
Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	103
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.7. Packet Type: 104 PMTK_CMD_FULL_COLD_START

This message is essentially a cold restart, but additionally clear system and user configurations at re-start. That is, reset the GPS module to the factory status. Full cold start means the GPS module has no information on last location. It needs to search the full time and frequency space, and also all possible satellite numbers before it can get a fix.

Data Field: None Example: \$PMTK104*37<CR><LF>	
Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	104

*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.8. Packet Type: 161 PMTK_CMD_STANDBY_MODE

This message is used to enter standby mode for power saving.

Data Field:
\$PMTK161,Type
Example:
\$PMTK161,0*28<CR><LF>
Response:
\$PMTK001,161,3*36<CR><LF>

Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	161
Type	'0'=Stop mode
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.9. Packet Type: 220 PMTK_SET_POS_FIX

This message is used to set position fix interval.

Data Field:
\$PMTK220, Interval
Example:
\$PMTK220,1000*1F<CR><LF>
Response:

\$PMTK001,220,3*30<CR><LF>

Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	220
Interval	Position fix interval [msec]. Must be greater than 200
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.10. Packet Type: 251 PMTK_SET_NMEA_BAUDRATE

This message is used to set NMEA port baud rate. Using PMTK251 command to setup baud rate setting, the setting will be back to default value in the condition: Full cold start command is issued.

Data Field:

\$PMTK251,Baudrate

Example:

\$PMTK251,38400*27<CR><LF>

Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	251
Baud Rate	Baud rate setting: 9600 - default setting 4800 9600 14400 19200 38400 57600 115200

*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.11. Packet Type: 255 PMTK_SET_SYNC_PPS_NMEA

This message is used to enable or disable fix NMEA output time behind PPS function.(Default off)

Data Field:
\$PMTK255,Enable
Example:
\$PMTK255,0*2C<CR><LF>
Response:
\$PMTK001,255,3*32<CR><LF>

Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	255
Enable	'0'=Disable '1'=Enable
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.12. Packet Type: 285 PMTK_SET_PPS_CONFIG

This message is used to set PPS type.

Data Field:
\$PMTK285,Type,PPSPulseWidth
Example:
\$PMTK285,4,100*38<CR><LF>

Response:
\$PMTK001,285,3*3F<CR><LF>

Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	285
Type	'0'=Disable '1'=After the first fix '2'=3D fix only '3'=2D/3D fix only '4'=Always
PPSPulseWidth	2~998 (Unit: ms)
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.13. Packet Type: 286 PMTK_SET_AIC_ENABLED

This message is used to enable or disable AIC function. It is suggested to set cold start command first and then PMTK command.

Data Field:
\$PMTK286,Enable
Example:
\$PMTK286,0*22<CR><LF>
Response:
\$PMTK001,286,3*3C<CR><LF>

Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	286
Enable	'0'=Disable '1'=Enable

*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.14. Packet Type: 301 PMTK_API_SET_DGPS_MODE

This message is used to configure the source mode of DGPS correction data.

Data Field:
\$PMTK301,Mode
Example:
\$PMTK301,1*2D<CR><LF>
Response:
\$PMTK001,301,3*32<CR><LF>

Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	301
Mode	DGPS data source mode. '0'=No DGPS source '1'=RTCM mode
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.15. Packet Type: 314 PMTK_API_SET_NMEA_OUTPUT

This message is used to set NMEA sentence output frequencies. There are totally 19 data fields that present output frequencies for the 19 supported NMEA sentences individually.

Supported Frequency Settings:

- 0 - Disabled or not supported sentence
- 1 - Output once every one position fix
- 2 - Output once every two position fixes
- 3 - Output once every three position fixes
- 4 - Output once every four position fixes
- 5 - Output once every five position fixes

Data Field:

None

Example:

The module only output RMC once every one position fix.

```
$PMTK314,0,1,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0*29<CR><LF>
```

Response:

```
$PMTK001,314,3*36<CR><LF>
```

Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	314
0 GLL	GLL interval - Geographic Position - Latitude longitude
1 RMC	RMC interval - Recommended Minimum Specific GPS Sentence
2 VTG	VTG interval - Course Over Ground and Ground Speed
3 GGA	GGA interval - GPS Fix Data
4 GSA	GSA interval - GPS DOPS and Active Satellites
5 GSV	GSV interval - GPS Satellites in View
6 GRS	GRS interval – GPS Range Residuals
7 GST	GST interval – GPS Pseudorange Error Statistics
8 Reserved	Always 0
9 Reserved	Always 0
10 Reserved	Always 0
11 Reserved	Always 0

12 Reserved	Always 0
13 Reserved	Always 0
14 Reserved	Always 0
15 Reserved	Always 0
16 Reserved	Always 0
17 ZDA	ZDA interval - Time and Date
18 MCHN	PMTKCHN interval - GPS channel status
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

To restore the system default setting, use below message:

Example:
\$PMTK314,-1*04<CR><LF>

Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	314
Restore	Always -1
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.16. Packet Type: 386 PMTK_API_SET_STATIC_NAV_THD

This message is used to set the speed threshold for static navigation. If the actual speed is below the threshold, output position will keep the same and output speed will be zero. If threshold value is set to 0, this function is disabled.

Data Field:
\$PMTK386,Speed_threshold
Example:
\$PMTK386,0.3*3E<CR><LF>
Response:
\$PMTK001,386,3*3D<CR><LF>

Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	386
Speed_threshold	0~2m/s
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.17. Packet Type: 400 PMTK_API_Q_FIX_CTL

This message is used to query the rate of position fixing activity.

Refer to PMTK_API_SET_FIX_CTL for setting the rate.

Refer to PMTK_DT_FIX_CTL for the result of the query.

Data Field:
None
Example:
\$PMTK400*36<CR><LF>

Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	400

*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.18. Packet Type: 401 PMTK_API_Q_DGPS_MODE

This message is used to query the setting of DGPS mode.

Refer to PMTK_API_SET_DGPS_MODE for setting the DGPS mode.

Refer to PMTK_DT_DGPS_MODE for the result of the query.

Data Field: None Example: \$PMTK401*37<CR><LF>	
Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	401
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.19. Packet Type: 414 PMTK_API_Q_NMEA_OUTPUT

This message is used to query the current NMEA sentence output frequencies.

Refer to PMTK_API_SET_NMEA_OUTPUT for the frequencies setting.

Refer to PMTK_DT_NMEA_OUTPUT for the result of the query.

Data Field:
None
Example:
\$PMTK414*33<CR><LF>

Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	414
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.20. Packet Type: 605 PMTK_Q_RELEASE

This message is used to query the firmware release information.

Refer to PMTK_DT_RELEASE for the result of the query.

Data Field:
None
Example:
\$PMTK605*31<CR><LF>

Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	605
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.21. Packet Type: 500 PMTK_DT_FIX_CTL

This message is the response to PMTK_API_Q_FIX_CTL.

Data Field:
\$PMTK500,Fix interval
Example:
\$PMTK500,1000,0,0,0,0*1A<CR><LF>

Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	500
Fix Interval	Position fix interval [msec]. Greater than 100
Reserved	Always 0
Reserved	Always 0
Reserved	Always 0
Reserved	Always 0
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.22. Packet Type: 501 PMTK_DT_DGPS_MODE

This message is the response to PMTK_API_Q_DGPS_MODE.

Data Field:
\$PMTK501,Mode
Example:
\$PMTK501,1*2B<CR><LF>

Field	Description
-------	-------------

\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	501
Mode	DGPS data source mode. '0'=No DGPS source '1'=RTCM mode
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.23. Packet Type: 514 PMTK_DT_NMEA_OUTPUT

This message is the response to PMTK_API_Q_NMEA_OUTPUT.

Data Field:

None

Example:

\$PMTK514,1,1,1,1,1,1,0,0,0,0,0,0,0,0,0,0,0*2E<CR><LF>

Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	514
0 GLL	GLL interval - Geographic Position - Latitude longitude
1 RMC	RMC interval - Recommended Minimum Specific GPS Sentence
2 VTG	VTG interval - Course Over Ground and Ground Speed
3 GGA	GGA interval - GPS Fix Data
4 GSA	GSA interval - GPS DOPS and Active Satellites
5 GSV	GSV interval - GPS Satellites in View
6 GRS	GRS interval - GPS Range Residuals

7 GST	GST interval – GPS Pseudorange Error Statistics
8 Reserved	
9 Reserved	
10 Reserved	
11 Reserved	
12 Reserved	
13 Reserved	
14 Reserved	
15 Reserved	
16 Reserved	
17 ZDA	ZDA interval - Time and Date
18 MCHN	PMTKCHN interval - GPS channel status
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.24. Packet Type: 705 PMTK_DT_RELEASE

This message is the response to PMTK_Q_RELEASE.

Data Field:

\$PMTK705, Release string, Build ID, Product Model(,SDK Version)

Example:

\$PMTK705,AXN_2.10_3339_13071501,0002,QUECTEL-L80-R,*1B<CR><LF>

Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	705

Release String	Firmware release name and version 3318: Mcore_x.x 3329: AXN_x.x 3339: AXN_x.x 3333: AXN_x.x 3337: AXN_x.x
Build ID	Build ID set in CoreBuilder for firmware version control
Product Model	Product Model set in CoreBuilder for product identification
SDK Version (Optional)	Showing SDK version if the firmware is used for SDK
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.25. Packet Type: 869 PMTK_EASY_ENABLE

This message is used to enable or disable EASY function, and it also can be used to query if EASY is enabled or disabled.

Data Field:
\$PMTK869,CmdType[, Enabled]
Example:
\$PMTK869,1,1*35<CR><LF>
Response:
\$PMTK001,869,3*37<CR><LF>

Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	869
CmdType	'0'=Query '1'=Set '2'=Result for Query operation
Enabled	'0'=Disable '1'=Enable
*	End character of data field

Checksum	Hexadecimal checksum
<CR><LF>	Each of message

3.26. Packet Type: 886 PMTK_FR_MODE

This message is used to set navigation mode.

Data Field: \$PMTK886,CmdType Example: \$PMTK886,3*2B<CR><LF> Response: \$PMTK001,886,3*36	
Field	Description
\$	Each NMEA message starts with '\$'
PMTK	MTK proprietary message
Packet Type	886
CmdType	'0'=Normal mode: For general purpose '1'=Fitness mode: For running and walking purpose that the low-speed (<5m/s) movement will have more effect on the position calculation. '2'=Aviation mode: For high-dynamic purpose that the large-acceleration movement will have more effect on the position calculation. '3'=Balloon mode: For high-altitude balloon purpose that the vertical movement will have more effect on the position calculation.
*	End character of data field
Checksum	Hexadecimal checksum
<CR><LF>	Each of message

4 Appendix A Reference

Table 3: Related Documents

SN	Document Name	Remark
[1]	Quectel_L80-R_Hardware_Design	L80-R Hardware Design
[2]	Quectel_L80-R_EVB_User_Guide	L80-R EVB User Guide
[3]	Quectel_L80-R_Reference_Design	L80-R Reference Design

Table 4: Terms and Abbreviations

Abbreviation	Description
GPS	Global Navigation Satellite System
NMEA	National Marine Electronics Association
PMTK	Private protocol of MTK
GGA	NMEA: Global Positioning System Fix Data
RMC	NMEA: Recommended Minimum Position Data
GSA	NMEA: GPS DOP and Active Satellites
GSV	NMEA: GPS Satellites in View
GLL	NMEA: Geographic Position – Latitude/Longitude
VTG	NMEA: Track Made Good and Ground Speed
AGPS	Assisted Global Positioning System
DGPS	Differential Global Positioning System
AIC	Active Interference Cancellation
PDOP	Position Dilution of Precision

VDOP	Vertical Dilution of Precision
HDOP	Horizontal Dilution of Precision
EASY	Embedded Assist System
PPS	Pulse Per Second
UTC	Universal Time Coordinated

Quectel
Confidential

5 Default Configurations

Table 5: Default Configurations

Item	Default
NMEA port baud rate	9600bps
Datum	WGS84
Rate of position fixing	1HZ
DGPS mode	Off
EASY enable	Enable
NMEA output messages	RMC, VTG, GGA, GSA, GSV and GLL
AIC	On